

# TABLET KIOSKS SOLUTIONS

## Kiosk Gooseneck

The Gooseneck design allows flowing movement, with totally flexible positioning for user comfort. View at any angle / orientation. Simple to secure to a counter or desktop, the perfect choice for creating your own tablet information bar. Available in white or black.



The Gooseneck can be fitted to most surfaces from above or below

## Kiosk Desktop Stand 30° & 60°

For complete versatility the Desktop Stand can be placed on any surface without making it a permanent fixture. Available in white or black and a choice of 30° or 60° viewing angle. We offer a Security Cable Kit to prevent theft

**Security Cable option** SecKit #



## Kiosk Pole 30° & 60°

The elegant angled Kiosk Pole brings beauty and symmetry to your tablet display. Set up in either Portrait or Landscape orientation. Available in 30° & 60° viewing angle options. Simple to secure to a counter or desktop, the natural choice for creating your own tablet information bar. Available in white or black.

The Pole can be fitted to most surfaces from below or above



## Kiosk Wall Mounted 30° & 60° & 90°

Offering a choice of three viewing angles, the wall-mounted kiosk is truly versatile. Set up in either Portrait or Landscape orientation. Available in 30°, 60° & 90° viewing options. Easily fitted to solid or partition walls for totally discreet cable management. Available in white or black.



## Kiosk Floor Stand 30° & Gooseneck

Ideal for exhibitions, showrooms and other open areas, the Kiosk Floor Stand provides the perfect platform to present information wherever it is needed. With a height of 1150mm and optimum 30° viewing angle it is stylish and practical. For extra flexibility choose the Gooseneck option. Available in white or black.

The 6.5Kg base promises complete stability. **Security Cable option** SecKit #



## Optional Security Kit for Desktop & Floor Stands

1.8m 19 Strand PVC Coated 6mm Steel Cable with end for padlock

**Padlock Keyed Alike available**

Anchor Kit to make a permanent anchor point.  
Anchor & 2 Wood Screws 25mm, Super Glue, Alcohol Wipe. SecKit #





# WHAT MAKES IT BETTER THAN THE REST?

We offer the best and **strongest metal / ABS Kiosk in the world**. Our product range provides:

- A variety of flexible designs including goose neck, desk top stand, pole, wall, flip & floor standing kiosks.
- Optional angles 30° 60° 90° and goose neck (with new metal base available).
- Options of rotate 90° (portrait to landscape) and swivel 270° for positional viewing.
- A strong lock with KA (keyed alike) or KD (keyed to differ) choices.
- The strong metal front cover plate (FCP) with strengthening bars & security screw housing.
- The 4 security screws that attach to the FCP making it the most secure and strongest metal / ABS kiosk available.
- Security slot for attachment of a security cable.
- Stylish design in Arctic White & Jet Black (wipe clean)



**Security Slot**



**FCP Front Cover Plate**



**Other Kiosks have a design flaw** in that their front cover plate has 2 prongs that slide into slots in the ABS rear section. A knife can be forced between the front cover plate and the ABS Kiosk breaking them apart in seconds.

**The tablet is stolen and kiosk is now scrap. A very expensive design flaw!**

Coming from an engineering and a security background and with over 28 years experience. Nexus understand how to improve our current design and how to foil that type of attack. With that in mind, our kiosk has been designed with the brief to design and make the strongest and best metal / ABS Kiosk in the world. Part of our solution is to add 4 security screws which prevent and protect the iPad / tablet from being stolen. When you tighten the 4 security screws they pull and lock everything together thus eliminating the attack threat problem, making this kiosk stronger and more secure than any other metal / ABS Kiosk available. Add a strong, secure lock with its key options and a security cable slot.


**Your iPad / tablet and Kiosk are safe and protected against theft.**



iPad 2,3,4, iPad Air & Air 2, iPad Mini



Tab 4



**Goose Neck**  
New Metal Base Available



**DeskTop Stand**  
90° Rotate 270° Swivel




**Pole**  
90° Rotate 270° Swivel



**Wall**




**Floor**



**Flip 45**



# WHAT MAKES IT BETTER THAN THE REST?



270° Swivel



Key Alike KA  
Keyed to Differ KD  
Lock Options



iPad 2,3,4, iPad Air & Air 2, iPad Mini



Tab 4



## Inside the Kiosk

### 1 (for iPad Air)

Silicone Corners can be cut to fit for other tablets.

Pop in the **Height Spacers**

Fits most 10.1" Tablets

iPad 2/3/4/ iPad Air

### 2

Feed the Power cable down the tube connect and Insert the tablet.


### 3

Place and lock the front Cover

### 4

DONE


## Ready to use



## Fixings Supplied.

**A** Gooseneck **B** Pole 30° **C** Pole 60° **D** Kiosk Screws (4) **E** Silicone Corners (4)  
**F** Silicone Height Spacers (4) **G** Metal Base Plate **H** Base Plate Screws (3)  
**I** Screws & Rawlplugs for Surface Mounting (4) **J** Plastic Cover  
**K** Plastic Cover Screw **L** Kiosk Keys (2) **M** Hex Head Tool

ONLY ONE POLE supplied according to your choice.



## Adjusting the Silicone Corner Pieces.

Supplied for the iPad Air, Air 2 but can be adjusted to accommodate most tablets

**1** Place the tablet onto the corner pieces mark with a pen and cut to shape.

**2** Place in Kiosk insert the tablet.




## Security Screws # (optional extra) Gooseneck Pole & Wall Mount

Security Screws Available with a choice of Driver bits





## Fitting Instructions Desktop Stand




Overall View – Parts

Keys Hex Tool

Tablet (Not Provided)

Face Plate


Pole



Kiosk

Lock

Base



Designed for iPad 2/3/4/ Air and Air2

Silicon Pads can be cut to size to accommodate most 10.1 Tablets

Front Cover Plate made of Steel

Lined with anti-shock foam inside to protect tablet screen

Kiosk Made from ABS Plastic

Kiosk lined with anti-shock foam to prevent damage.

Metal Base for Gooseneck, Pole and Wall Kiosks, takes power cable

Pole and Wall Kiosks Tubing made from Aluminium, takes power cable

Large Aluminium CNC Base on the Desktop Stand

Supplied with 2 keys

Tablet charged while in use 100% WIFI Friendly

Tools inc Key x 2, All Screws, Hex Head Allen Keys

**Equipment needed Drill & Cross head screw driver on  
Gooseneck, Pole, Wall Kiosk, Security Cable Kit**



**1** Fit the Base to the Pole with the  
4mm Hex Screws



**2** Fix the Kiosk to the pole

**1A**

**NOTE ADD SECURITY CABLE LOOP A ROUND THE POLE SECTION at this point  
if you have ordered one**



**3** Put the charging Cable through the Pole



**4** open the face plate with the key



**5** Put the tablet in the Kiosk attach Power cable  
Attach Face Plate Cover and Lock. FINISHED



**6** Ready to go.

## Fitting Instructions Gooseneck, Pole & Wall



**1** Attach Metal Base  
Countersunk Screw (3)



**2** Screw Down  
Long Screws (4)



**3** Attach Plastic Cover  
Small Hex head Screw

### SURFACE MOUNTED

**NB** Pass the power cable through first, for Surface Mounting.  
If you are going through the desktop pass the power cable through after fitting.



**4** Fix the Kiosk to the pole  
Put the charging Cable through the Pole



**4** open the face plate with the key



**5** Put the tablet in the Kiosk attach Power cable  
Attach Face Plate Cover and Lock. FINISHED



**6 Ready to go**

Designed for iPad 2/3/4/ Air and Air2

Silicone Pads can be cut to size to accommodate most 10.1 Tablets

Front Cover Plate made of Steel

Lined with anti-shock foam inside to protect tablet screen

Kiosk Made from ABS Plastic

Metal Base for Gooseneck, Pole and Wall Kiosks, takes power cable

Pole and Wall Kiosks Tubing made from Aluminium, takes power cable

Large Aluminium CNC Base on the Desktop Stand

Supplied with 2 keys

Tablet charged while in use 100% WIFI Friendly

Tools inc Key x 2, All Screws, Hex Head Keys

## Equipment needed Drill & Cross head screw driver on Gooseneck, Pole, Wall Kiosk, Security Cable Kit



Overall View – Parts

Keys Hex Tool


Tablet (Not Provided)

Face Plate

Goose Neck Pole  
Wall



## Fitting Instructions – Floor Stand



## Kiosk

5 Secure Kiosk to the pole (4 Screws)

6 Remove the Face Plate Cover

7 Feed the Power cable down the pole

8 insert Tablet replace Face Plate Cover & Lock

