

3 Smithy Green, OFF Huddersfield Road, Ogden, Newhey, Rochdale OL163TG









## MMC iTab Dreadnought Cable Anchor

Fitting using a iTab, a Dreadnought cable and a Anchor point



- 1 Attach the Anchor to the underside of the table.
- 2 Tread the Dreadnought cable through the anchor & through the loop.
- 3 Bring around and secure to the MMC.



iTab, Remove the double sided tape secure to the base of the MMC avoiding the reset / power on buttons

- 1 Attach the Anchor to the underside of the table.
- 2 Tread the Dreadnought cable through the anchor & through the loop.
- 3 Drill a 6mm Hole in the table top
- 4 Remove the Dreadnought head pass the cable through the hole.
- 5 Reattach the Dreadnought head.
- 6 Secure to the MMC

You can also loop the Dreadnought around the leg then go to stage 3 This way reduces the chance of MMC being knocked off the table.

NB Drill close to the table centre.



